

Quadraspire X Reference rack instructions



CAUTION:

Please note columns & feet are made from solid aluminium which is a soft metal and therefore it is important to take care when screwing them together. Once rack has settled after a few days it is advisable to re-tighten the columns.



STEP 1

Insert column thread through the hole in the X Reference shelf and screw on the foot. Make sure that chamfered edge of the shelf is facing down.



STEP 2

Then level shelf by adjusting the spikes. May need to do this again once the whole rack is built.



STEP 3

Add shelves and columns as required. Once complete, hand tighten all the columns working up from the bottom.



STEP 4

Insert SV Bronze top bolt thread through the hole in SVT bamboo shelf and screw on Bronze lock nut.



STEP 5

Screw SV Bronze spike into the Bronze top bolt.



STEP 6

Place Bronze locators into the 4 holes on X Reference shelf and then locate SVT shelf and SV Bronze spikes onto the locators.



STEP 7

Add SVT shelf to each level of X Reference rack. Each SVT shelf needs to be levelled by adjusting SV spike and lock nut.

Quadraspire

Should you need any advice or have any questions please do not hesitate to call our sales team either by phone 01761 452178 or e-mail sales@quadraspire.co.uk



QUADRASPIRE LIMITED

Unit 2 Hallatrow Business Park,
Wells Road, Hallatrow, BS39 6EX, England
sales@quadraspire.co.uk